

Angle Grinder

Overview

We have an angle grinder in the workshop. This is used for making cuts in metals. This is to be only used within the weldy / grindy area, NOT the main metal work area, we have to avoid any particles entering into the lathe or milling machines.

Notes

There is a packet of spare discs in the box with the grinder, as well as the spanner for changing them. Remember that the discs wear with use - if you're doing a lot of cutting (or cutting through something very tough) and thus using a lot of discs, it would be polite to replace what you use

Safety

- Find a way to fasten the part down, ether by clamps or vice
- **DO NOT** use the grinder in the main metal work area, only the weldy grindy area next door.
- Make sure to use the right type of disc for the job (don't grind with a cutting disc)
- Wear lots of ppe, Gloves, Impact Googles, hearing protection, mask if grinding anything that would generate dust
- No lone working
- Don't overload / burn out the grinder by pushing it too hard (this happened with a dewalt one we had)

Risk Assesments

- [Angle-Grinder-Risk-Assessment.ods](#)
- [Angle-Grinder-Risk-Assessment.pdf](#)

From:
<http://testwiki.hecatron.com/> - Hacman DEMO ONLY

Permanent link:
<http://testwiki.hecatron.com/doku.php?id=workshop:metalwork:equipment:angle-grinder&rev=1667682741>

Last update: 2022/11/30 16:28

